
EPON OLT Configuration Guide

Version: V1.2

Directory

| | |
|--|----|
| Overview..... | 3 |
| Command Conventions..... | 3 |
| Keyword Operation Conventions..... | 3 |
| Common command..... | 3 |
| Symbol Conventions..... | 4 |
| Terms Conventions..... | 4 |
| Prompt..... | 4 |
| 1. System Access..... | 4 |
| 1.1 Overview..... | 4 |
| 1.2 Console Access..... | 5 |
| 1.3 Out-band interface access (From OLT MGMT/AUX port)..... | 6 |
| 1.4 In-band Interface Access(From OLT Ge uplink port)..... | 7 |
| 2. Upgrade OLT..... | 8 |
| 2.1 Note: | 8 |
| 2.2 Upgrade Tutorial..... | 8 |
| 2.3 Web Management System Upgrade Guide..... | 12 |
| 3. Application Example..... | 15 |
| 3.1 Data Plan..... | 15 |
| 3.2 Configure OLT..... | 16 |
| 3.3 Configure the ONU..... | 18 |
| 3.3.1 Configure Internet Services of Bridged ONU..... | 18 |
| 3.3.2 Configuring IPTV Service of Bridge ONU..... | 19 |
| 3.3.3 Configuring Gateway ONU Internet Service – RTK chip scheme ONU..... | 22 |
| 3.3.4 Configuring Gateway ONU IPTV Service – RTK chip scheme ONU..... | 24 |
| 3.3.5 Configuring Gateway ONU Internet Service – Broadcom chip scheme ONU..... | 25 |
| 3.3.6 Configuring Gateway ONU IPTV Service – Broadcom chip scheme ONU..... | 29 |
| 3.3.7 Configuring Gateway ONU VOIP Service – Broadcom chip scheme ONU..... | 31 |

Overview

Command Conventions

The command conventions that may be found in this document are defined as follows.

| Convention | Description |
|-----------------|---|
| Boldface | The keywords of a command line are in boldface . |
| <i>Italic</i> | Command arguments are in <i>italics</i> . |
| [] | Items (keywords or arguments) in brackets [] are optional. |
| (x y ...) | Optional items are grouped in braces and separated by vertical bars. One item is selected. |
| [x y ...] | Optional items are grouped in brackets and separated by vertical bars. One item is selected or no item is selected. |
| <x-y> | One number from x to y can be selected |
| \$ | A line starting with the \$ sign is comments. |

Keyword Operation Conventions

| Convention | Description |
|-----------------|--|
| String with < > | It is key name. For example, <Enter>, <Tab>, <Backspace>, <a>, <?> etc, it means to press the key button |
| <Key 1 + Key 2> | It means to press the key at same time. For example <Ctrl+Alt+A> means to press "Ctrl", "Alt", "A" button together. |
| <Key 1 , Key 2> | It means to press the first button, then release, and press the second button. For example < Alt, F> means to press "Alt" first, then release "Alt" button, and then press "A" button. |

Common command

| command | description |
|-------------------------|--|
| show vlan all | View OLT vlan summary |
| show system infor | View OLT information of version, MAC, sequence number, model |
| show igmp group all | View the list of multicast groups that the OLT joins |
| show running-config all | View the running configuration of the OLT |

| | |
|-------------------------------------|---|
| show startup-config all | View the saved configuration of the OLT |
| show system ipconfig | View the in-band, out-of-band management IP address information of the OLT |
| show olt 1 onu 1 ctc sn | View the version information for the ONU |
| show olt <oltId> online-onu | View the online ONU on the PON port |
| show olt <oltId> optical-online-onu | View all the online ONU information of optical power, voltage, current, temperature and so on |

Symbol Conventions

The symbols that may be found in this document are defined as follows.:



This warning symbol means danger. You are in a situation that could cause bodily injury or broke the equipment. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents by making quick guide based on this guide.



Indicates a hazard with a high level of risk, which if not avoided, it will result in death or serious injury on human body.



Provides additional information to emphasize or supplement important points of the main text.

Terms Conventions

OLT: It is the Optical Line Terminal, included the switch and uplink port.

PON: It stand for PON protocol process module and PON port to connect with ONU side.

Prompt


CLI is case – sensitive.

1. System Access

1.1 Overview

The CLI of OLT can be configured and managed via local terminal connection or a remote session using Telnet. The OLT supports three methods to gain access for management and configuration tasks:

1. Local access to the OLT through the RS232 console port on front panel, see below picture.
2. Dedicated local Telnet connection to the OLT by using the FE port on OLT front panel (outband interface).
3. Remote access over the provider’s Ethernet/IP network by using Telnet. Therefore, an inband management channel.



图表 1

1.2 Console Access

OLT provides console interface (marked as “CONSOLE” RJ45 type port) .

Console access requires:

- Console cable: RJ-45-to-DB-9 console cable
- Terminal emulation software: HyperTerminal

The cable is connected between the serial port of the host and the console port on the device. Most computers and notebooks no longer include built-in serial ports. If the host does not have a serial port, the USB port can be used to establish a console connection. A special USB-to-RS-232 compatible serial port adapter is required when using the USB port.

- RJ-45-to-DB-9 Console Cable, as follows:

| Port on Computer | Cable Required | Port on OLT |
|------------------|---|--------------------|
| Serial Port | RJ-45 to DB-9 Console Cable | RJ-45 Console Port |
| USB Type-A Port | <ul style="list-style-type: none"> ● USB to RS-232 compatible serial port adapter (Adapter may require a software driver) ● RJ-45 to DB-9 Console Cable | |



RJ-45 to DB-9 Console Cable



USB to RS-232 compatible serial port adapter

Run a VT terminal emulation software (e.g. HyperTerminal) with the attributes

Band Rate: 9600


Data Bit: 8

Parity Check: NO

Stop Bit: 1

Flow Control: NO

When the serial port tool is successfully connected to the OLT, in the actual command line, username input admin, password input admin (The password will not be displayed). As follows:



1.3 Out-band interface access (From OLT MGMT/AUX port)

You should configure your PC IP to 192.168.1.X (Except 192.168.1.100), connect to the MGMT/AUX port of OLT, login the OLT with the default OLT management IP (Default IP : 192.168.1.100). Default login ID is admin and the password is admin. As follows:

```
管理员: C:\Windows\system32\cmd.exe
Microsoft Windows [版本 6.1.7601]
版权所有 (c) 2009 Microsoft Corporation。保留所有权利。

C:\Users\Administrator.PC-20131223UEFH>telnet 192.168.1.100
半:
```

```
Telnet 192.168.1.100
*****
Command Line Interface for EPON System
Hardware Ver: U3.1
Software Ver: 2.4.01_B1_000
Created Time: Feb 16 2017 11:52:55
Copyright (c) 2006-2015 All rights reserved.
*****
Username: admin
Password:
epon#
半:
```

1.4 In-band Interface Access(From OLT Ge uplink port)

You should configure your PC IP to 192.168.8.X (Except 192.168.8.100), connect to the uplink port of OLT, login the OLT with the default OLT in-band management IP (Default IP : 192.168.8.100). Default login ID is admin and the password is admin.As follows:

```
管理员: C:\Windows\system32\cmd.exe
Microsoft Windows [版本 6.1.7601]
版权所有 (c) 2009 Microsoft Corporation。保留所有权利。

C:\Users\Administrator.PC-20131223UEFH>telnet 192.168.8.100
半:
```

```
Telnet 192.168.8.100
*****
Command Line Interface for EPON System
Hardware Ver: U3.1
Software Ver: 2.4.01_B1_000
Created Time: Feb 16 2017 11:52:55
Copyright (c) 2006-2015 All rights reserved.
*****
Username: admin
Password:
epon#
```

2.Upgrade OLT

2.1Note:


The new version(OLT V2.3.X) is different from the olt version(before OLT V2.3.X). There are two management IP in the new version, such as in-band management IP and out-of-band management IP. But There is only one management IP in the old version.

So we adjust something about the in-band and out-of-band management IP. As follows:

- 1. Before the OLT is default ip address 192.168.1.100,after upgrade to V2.3.1 version:**
OLT uplink port manage ip address is:192.168.8.100
OLT AUX/MGMT port manage ip address is:192.168.1.100
- 2. Before the OLT manage ip address have been change to 192.168.1.X not is 192.168.1.100 ,after upgrade to V2.3.1 version:**
OLT uplink port manage ip address is:192.168.1.X
OLT AUX/MGMT port manage ip address is:192.168.2.100
- 3. Before the OLT manage ip address have been change to other not is 192.168.1.X ,after upgrade to V2.3.1 version:**
OLT uplink port manage ip address is:It is before you are changed ip address.
OLT AUX/MGMT port manage ip address is:192.168.1.100


2.2Upgrade Tutorial

There is a topology for upgrading, As follows:




Note : This tutorial will take the PC as a server, and the IP of PC is 192.168.1.11, management IP of the OLT is 192.168.1.100.

1. Make sure that the firewall on the PC is turned off;
2. Ensure that the IP address of the PC and the management IP of the OLT are on the same network segment and can ping each other; As follows:



图表 8

3. Ensure that there is TFTP program on the PC to download the firmware for the OLT. As follows:
 - (1) Specifies the path to the firmware to be upgraded;
 - (2) Specifies the IP address of the server (ie PC);





图表 9

4. Enter the upgrade command in the OLT


epon# **system update firmware < firmware name> tftp-server <tftp-ip>**

As follows:

- (1) < firmware name > : V2.4.01_B1_170216.img, <tftp-ip>:192.168.1.11。
- (2) Upgrade command input is completed, you can see tftp server has the process of transferring firmware.
- (3) After the upgrade, enter "y" to restart the OLT. (Note: must be restarted, OLT can apply the new version of the software)



5.Upgrade succeeded; As follows:



2.3 Web Management System Upgrade Guide

1. Upgrade OLT basic firmware to latest basic firmware which packaged with latest web firmware. The latest OLT basic firmware is: V2.4.02_170421_X000.

img

EX:

```
epon# system update firmware V2.4.02_170421_X000.img tftp-server 192.168.1.11
```

Transferring the Image file, please wait...

Earsing flash, please wait...

Upgrading image, please wait.....OK!

Reboot the system now<y/n>?y

2. Check whether the OLT basic firmware upgrade successfully

```
epon# show system infor
```

```

-----
Software Version : 2.4.02_000(Apr 21 2017)
Hardware Version : V3.1
MAC : e0-67-b3-00-57-41
Serial Number : AF1101-16080032
System Time : 2000/01/09 02:22:02 +08:00

```

```
-----  
System Temperature : 41.5C  
FAN[1]             : Normal  
FAN[2]             : Normal  
FAN[3]             : Normal  
-----
```

3. Use `system update web-server` command to upgrade OLT web firmware. The latest web firmware is: `WEB_V1.0.0_170421_1831.img`

Note: 4pon port OLT and 8 pon port OLT use same web firmware.

EX:

```
epon# system update web-server WEB_V1.0.0_170421_1831.img tftp-server 192.168.1.11  
Transferring the Web Server file, please wait...  
Upgrading Web Server ...  
Restarting Web Server ...  
OK!
```

4. After upgrading web firmware do not need to reboot the OLT. Check whether the web firmware is correct directly.

```
epon# show system infor
```

```
-----  
Software Version   : 2.4.02_000(Apr 21 2017)  
Hardware Version   : V3.1  
MAC                : e0-67-b3-00-57-41  
Serial Number      : AF1101-16080032  
System Time        : 2000/01/09 02:32:04 +08:00  
-----
```


```
Web Server
```

```
Version            : V1.0.0  
BuildTime          : 17-04-21 18:31:25  
Administrator      : admin  
Password           : admin
```

```
-----  
System Temperature : 38.0C  
FAN[1]             : Normal  
FAN[2]             : Normal  
FAN[3]             : Normal  
-----
```

5. Use Firefox browser access to OLT web via inbound ip address or outband ip address. Then you can see the OLT web login interface. Web default login username and password is: admin/admin

Note: Recommend using Firefox web browser to access OLT web interface




6. Customized web management information configure. PC access to OLT web via <http://192.168.5.55/cgi/customer.php> And enter parameter. Click “OK” . Restart the OLT web in browser then can view the customized informations.

Language:Support Chinese and English. The default is Chinese.

Customer:Customer ID. The default is neutral.

SecretKey: Customer ID secretkey. The default is neutral.

Version: Customized web management system version.



7. Other instructions

a. Web management system’s username and password is independent, default is admin/admin. This username and password can modify in web interface and would not affect other access mode.


b.Web management system need to work in V2.4.02 OLT basic firmware. In old OLT basic version can’t not support the web function. So if you need to use web

function. Please upgrade OLT basic firmware to V2.4.02 or newer at first.

3. Application Example

This section describes basic concepts related to the fiber to the home (FTTH) solution from the user side to the network side on FTTH networking using PON transmission.

We will give two example of the configuration. One is Bridge ONU configuration, another is the Gateway ONT configuration.




3.1 Data Plan

The subsequent examples are configured based on the following data plan.

| Data Plan | |
|-------------------------|---|
| Service Classification | Data |
| VLAN | VLAN 100: Internet Service VLAN 200: IPTV Service VLAN 300: VOIP Service |
| OLT Port Setting | Ge5: Pvid is 100, VLAN 100 . Ge6: Pvid is 200, VLAN 200. Ge7: Pvid is 300, VLAN 300. PON1: VLAN 100 tag, VLAN 200 tag, VLAN 300 tag. |
| Bridge ONT Port Setting | LAN 1: VLAN 100, tag mode LAN 2: VLAN 200, tag mode |
| Gateway ONT Port | LAN1: VLAN 100 |

| | |
|---------|----------------------------------|
| Setting | LAN2: VLAN 200 POTS: VLAN 300 |
|---------|----------------------------------|

Configuration Process



3.2 Configure OLT

The configuration of OLT include pvid and vlan of ge port, vlan of pon port.

- Enable the vlan function
- Configure pvid and vlan for GE port: vlan mode include untag and tag.
- Configure pvid and vlan for PON port: vlan mode include untag and tag. (About the 8 port OLT, ge9-ge16 means PON port 1-8 in the CLI. About the 4 port OLT, ge5-ge8 means PON port 1-4 in the CLI.)

(1) Enable the vlan function

```
epon#swmode vlan enable
```

(2) Configure pvid and vlan for GE port

```
epon# swport ge1          // Enter ge1 configuration view
epon(GE-1)# pvid 100      //Pvid is 100
epon(GE-1)# vlan add 100  //Add vlan100, mode is untag
epon(GE-1)# exit
epon# swport ge2          // Enter ge2 configuration view
epon(GE-2)# pvid 200      // Pvid is 200
```



```

epon(GE-2)# vlan add 200           // Add vlan200, mode is untag
epon(GE-2)# exit
epon# swport ge3                   // Enter ge3 configuration view
epon(GE-3)# pvid 300                // Pvid is 300
epon(GE-3)# vlan add 300           // Add vlan300, mode is untag
epon(GE-3)# exit

```

(3) Configure pvid and vlan for PON port

```

epon# swport ge9
epon(GE-9)# vlan add 100,200,300 tag //Add vlan100,200,300on the GE9, mode is tag
epon(GE-9)# exit

```



Note:

1. If the port has only one vlan untag mode and the same as the pvid, then the port is access mode. This mode can be used when the uplink port can only handle devices that do not carry tag packets (such as PCs) or uplink networks without tagged packets. As follows:

```

epon# swport ge1                   // Enter ge1 configuration view
epon(GE-1)# pvid 100                // Pvid is 100
epon(GE-1)#vlan add 100             // Add vlan100, mode is untag

```

2. If the port is configured with multiple vlan and tag mode, the port is in trunk mode. You can set the port to this mode when the switch is connected to a switch or other device that can process packets with tagged messages. As follows:

```

epon# swport ge4                   // Enter ge4 configuration view
epon(GE-4)#pvid 10                  // Pvid is 10
epon(GE-4)#vlan add 10              //Add vlan10, mode is untag
epon(GE-4)# vlan add 11 tag          // Add vlan11, mode is tag
epon(GE-4)#vlan add 12 tag          // Add vlan12, mode is tag

```

3. If the port is configured with multiple vlan and some of which are tagged and the others are untag mode, the port is in hybrid mode. When the uplink network can handle the device with tag packets and only devices that can not process tagged packets (such as PC), the port can be set to this mode. As follows:

```

epon# swport ge5                   // Enter ge5 configuration view
epon(GE-5)#pvid 10                  // Pvid is 10
epon(GE-5)#vlan add 10              // Add vlan10, mode is untag
epon(GE-5)# vlan add 11             // Add vlan11, mode is untag
epon(GE-5)#vlan add 12 tag          // Add vlan12, mode is tag

```

(4) Configure GIMP and Multicast Vlan

```

epon# igmp mode proxy                // IGMP is proxy mode
epon#btv                             //Enter the btv view

```

```

epon(btv)# igmp user add user-index 1 pon 1 ont 1 vlan 200
// Add btv user binding specified ONU
// and vlan
epon(btv)#exit //Exit the btv view
epon# multicast-vlan 200 //Create and entermulticast
//vlan200 view
epon(multicast-vlan-200)# igmp router-port ge2 // Configure the multicast routing
// port as ge2
epon(multicast-vlan-200)# igmp member user-index 1 // Add multicast users to multicast
//vlan200
OLT(config-multicast-vlan-200)# igmp match group ip 224.1.1.1 to-ip 224.5.5.5
// Configure multicast vlan200 to match the multicast
//address segment 224.1.1.1-224.5.5.5
OLT(config-multicast-vlan-200)# exit //Exit the multicast vlan 200 view

```

3.3 Configure the ONU

3.3.1 Configure Internet Services of Bridged ONU

Only when the ONU register to the OLT success , you can configure the service of the ONT. So make sure ONU is registered to the OLT.

OLT would register ONT automatically in default.

Prerequisites

- The OLT is connected to the uplink device success
- The OLT create internet vlan
- The OLT configure GE port vlan for Internet
- The OLT configure PON port vlan for Internet
- The ONU is registered

Configure ONU port vlan

```

epon# olt 1 //Enter the PON port
epon(olt-1)# onu 1 //Enter the ONU
epon(olt-1/onu-1)# uni 1 //Enter the uni of ONU
epon(olt-1/onu-1/uni-1)# ctc vlan-mode tag 0x8100 0 100 // Configure the ONU port mode
// as tag mode (access mode)
epon(olt-1/onu-1/uni-1)#exit

```

3.3.2 Configuring IPTV Service of Bridge ONU

Prerequisites

- The OLT is connected to the uplink device success
- The OLT create IPTV vlan
- The OLT configure GE port vlan for IPTV
- The OLT configure PON port vlan for IPTV
- The OLT configure IGMP and Multicast vlan
- The ONT is registered

Configure ONU port

```
epon(olt-1/onu-1)# uni 2
epon(olt-1/onu-1/uni-2)# ctc vlan-mode tag 0x8100 0 200 // Configure the ONU port mode as
tag mode (access mode)
epon(olt-1/onu-1/uni-2)# ctc igmp vlan add 200 //Configure the multicast vlan as
200
```

Note:

The port mode of ONU is as follows:

1. Transparent Mode:

| Direction | Type | Processing method |
|------------|-------------|---|
| Upstream | Untag frame | Untag frame does not make any change, forwarding |
| | Tag frame | Tag frame does not make any changes (original VLAN TAG), forwarding |
| Downstream | Untag frame | Untag frame does not make any change, forwarding. |
| | Tag frame | Tag frame does not make any changes (original VLAN TAG), forwarding. |
| | Tag frame | Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; If the Tag frame VLAN does not belong to the port of the "permitted by VLAN," is discarded. |

Command is as follow:

```
epon(olt-1/onu-4/uni-1)# ctc vlan-mode transparent
```

2. Tag Mode (access Mode):

| Direction | Type | Processing method |
|------------|-------------|--|
| Upstream | Untag frame | Switch frames on port's default VLAN(VPID),forwarding. |
| | Tag frame | Discard the frame |
| Downstream | Untag frame | Discard the frame |
| | Tag frame | If the Downstream Tag frame VLAN ID equal to the configuration of the VID, According to VID forwarded to |

| | | |
|--|-----------|---|
| | | the appropriate UNI port, and stripping the tag; If the downstream Tag frame VLAN ID is not equal to the configuration of the VID, then the frame is discarded |
| | Tag frame | Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; If the Tag frame VLAN does not belong to the port of the "permitted by VLAN," is discarded. |

Command is as follow:

```
epon(olt-7/onu-1/uni-1)# ctc vlan-mode tag <tpid> <cos> <vlan>
```

3. Translation Mode:

| Direction | Type | Processing method |
|------------|-------------|--|
| Upstream | Untag frame | Switch frames on port's default VLAN(VPID),forwarding. |
| | Tag frame | Tag frame VLAN ID in the configuration of the VID conversion list, forwarding; Tag frame VLAN ID is not in the configuration of the VID conversion list, frame discarding. |
| Downstream | Untag frame | Discard the frame |
| | Tag frame | Tag frame VLAN ID corresponds to the entry in the corresponding port of the VLAN Translation list (equal to the input VID configuration), According to the table to convert the VID to a corresponding VID (VID output), forwarding; If the VLAN ID in the corresponding port of the VLAN Translation list without a corresponding entry, discarding; If the TAG frame with VLAN ID as the "default VLAN", after the VLAN label forwarding is stripped down; |
| | Tag frame | Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; If the Tag frame VLAN does not belong to the port of the "permitted by VLAN," is discarded. |

Command is as follow :

```
epon(olt-7/onu-1/uni-1)# ctc vlan-mode translation <tpid> <cos> <default-vlan>  
translate-list
```

4. Trunk Mode:

| Direction | Type | Processing method |
|-----------|-------------|---|
| Upstream | Untag frame | Switch frames on port's default VLAN(VPID),forwarding. |
| | Tag frame | Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; Tag frame VLAN ID does not belong to the port of the "permitted by VLAN," is discarded |
| Downstre | Untag frame | Discard the frame |

| | | |
|----|-----------|---|
| am | Tag frame | Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; Tag frame VLAN ID belongs to the port "allowed by VLAN", forwarding; If the Tag frame VLAN does not belong to the port of the "permitted by VLAN," is discarded. |
|----|-----------|---|

Command is as follow:

```
epon(olt-7/onu-1/uni-1)# ctc vlan-mode trunk <tpid> <cos> <default-vlan> vlan-list (选配)
```

5. Aggregation Mode:

| Direction | Type | Processing method |
|------------|-------------|--|
| Upstream | Untag frame | Switch frames on port's default VLAN(VPID),forwarding. |
| | Tag frame | <p>If the VLAN ID of the packet is equal to one of the "aggregated VLANs" in the VLAN aggregation table, the VID of the packet is converted to the corresponding VLAN to be agrg. The source of the service flow is also recorded. MAC address value, and forward;</p> <p>If the VLAN ID of the packet is not equal to any one of the "aggregated VLANs" in the VLAN aggregation table of the port, it is discarded.</p> <p>Currently, only the ONU is required to convert the VID. The conversion of other fields (such as TPID, CFI, and Pri) is not required. The ONU treats the TPID and Pri fields in the VLANConfig Parameters field of the received VLAN VariableContainer, After the TPID set to the default value (TPID = 0x8100), Pri to maintain the original value</p> |
| Downstream | Untag frame | Discard the frame |
| | Tag frame | <p>If the VLAN ID of the packet is equal to "VLAN to be agrg." In the VLAN aggregation table of the port, the VID is converted to the corresponding "aggregated VLAN" according to the MAC address value and forwarded.</p> <p>If the VID of the original tag is the default VID, the tag is forwarded and forwarded. If the VLAN ID is not equal to "VLAN to be agrg." Or the default VLAN ID is not equal, the ONU is only required VID conversion, other fields (such as TPID, CFI and Pri) conversion is not required. The ONU treats the TPID and Pri fields in the VLANConfig Parameters parameter field in the received VLAN VariableContainer and sets the TPID of the converted VLAN tag to the default value (TPID = 0x8100). Pri remains the original value.</p> |

Command is as follow:

```
epon(olt-7/onu-1/uni-1)# ctc vlan-mode aggregation <tpid> <cos> <default-vlan>
```

aggregation-list (选配)

---End

3. 3.3 Configuring Gateway ONU Internet Service – RTK chip scheme ONU

This topic describes how to configure Internet access service, voice service, BTV service and VoD service when gateway ONU is used to build an FTTH network.

The ONT integrating an IAD provides Internet, VoIP, and IPTV services to users. The Gateway ONU facilitates interconnection of home devices by providing Layer 3 services, such as Point-to-Point Protocol over Ethernet (PPPoE)/DHCP dial-up, network address translation (NAT), and Internet Group Management Protocol (IGMP) snooping. This scenario provides fine-grained management channels and service control, and mainly applies to Layer 3 networking.

Prerequisites

- The OLT is connected to the uplink device success
- The OLT create internet vlan
- The OLT configure GE port vlan for Internet
- The OLT configure PON port vlan for Internet
- The ONU is registered

1. Create Route WAN and bind LAN 1 in ONU Web

Click Internet→Internet Config→ WAN Config

WAN Config

| | |
|--|---|
| WAN Connection name | <input type="text" value="Add WAN connection"/> |
| Mode : | <input type="text" value="Route"/> |
| Connection Mode:: | <input type="text" value="Ipv4/Ipv6"/> |
| <input checked="" type="radio"/> DHCP | Obtain an IP address automatically |
| <input type="radio"/> Static | Use Static IP address |
| <input type="radio"/> PPPoE | PPP over Ethernet (PPPoE) |
| NAT: | <input checked="" type="checkbox"/> |
| Enable Vlan: | <input checked="" type="checkbox"/> |
| Vlan ID: | <input type="text" value="100"/> |
| 802.1p: | <input type="text" value="(NULL)"/> |
| MTU: | <input type="text" value="1500"/> |
| Request DNS: | <input checked="" type="radio"/> Enable |
| | <input type="radio"/> Disable |
| Primary DNS: | <input type="text"/> |
| Secondary DNS: | <input type="text"/> |
| Service Mode: | <input type="text" value="INTERNET"/> |
| Bind port: | |
| <input checked="" type="checkbox"/> Port_1 | <input type="checkbox"/> Port_2 |
| <input type="checkbox"/> Port_3 | <input type="checkbox"/> Port_4 |
| <input checked="" type="checkbox"/> wireless(SSID) | |

 **NOTE:**

Mode select to **Route**. Check **Enable VLAN** and Vlan ID input **100**. Service Mode select to **INTERNET**. Bind port check **Port_1** and **wireless(SSID)**.

Internet service document take DHCP mode as an example. The service type please selected according to the user's actual use. ONT detail usage please refer to ONT user manual.

2. Check ONU status

Click **Status**→**Internet Info**

| Status | Internet | Security | Application | Management | Diagnosis |
|----------------------------|---------------|------------|---------------|------------|---------------|
| Device Info | Internet Info | LAN & WLAN | TR-069 Status | | |
| WAN Info | | | | | |
| Interface | VLAN ID | Protocol | IGMP | Status | IP address |
| 1_TR069_R_VID_46 | 46 | IPoE | Enable | down | |
| 2_INTERNET_R_VID_100 | 100 | IPoE | Enable | up | 192.168.5.129 |
| Network Information | | | | | |
| Default Gateway | 192.168.5.254 | | | | |
| Subnet Mask | 255.255.255.0 | | | | |
| Primary DNS | 192.168.5.254 | | | | |
| Secondary DNS | | | | | |

3. 3.4 Configuring Gateway ONU IPTV Service – RTK chip scheme ONU

Prerequisites

- The OLT is connected to the uplink device success
- The OLT create IPTV vlan
- The OLT configure GE port vlan for IPTV
- The OLT configure PON port vlan for IPTV
- The OLT configure IGMP and Multicast vlan
- The ONT is registered

1. Create Bridge WAN and bind LAN 2 in ONU Web

Click **Internet**→**Internet Config**→ **WAN Config**

| Status | Internet | Security | Application | Management | Diagnosis |
|--|--|-------------|-------------|-------------|-------------|
| Internet Config | Port Binding | DHCP Server | WLAN Config | Remote Mgmt | QoS |
| | | | | | Time Config |
| | | | | | Routing |
| WAN Config | | | | | |
| WAN Connection name | Add WAN connection | | | | |
| Mode : | Bridge | | | | |
| Connection Mode:: | Ipv4/Ipv6 | | | | |
| Enable Vlan: | <input checked="" type="checkbox"/> | | | | |
| Vlan ID: | 200 | | | | |
| 802.1p: | (NULL) | | | | |
| Service Mode: | Other | | | | |
| Bind port: | <input type="checkbox"/> Port_1 <input checked="" type="checkbox"/> Port_2 <input type="checkbox"/> Port_3 <input type="checkbox"/> Port_4 <input type="checkbox"/> wireless(SSID) | | | | |
| <small>NOTE: Can not bind the same port to different WAN connection. If the same port has been binded to different WAN connection, the last configuration will flush your previous configurations on this port.</small> <small>When the Bridge mode is set to Other, the PC on the port does not dynamically obtain the IP address through the gateway. When the service mode is Other, please be careful not to bind all LAN ports for such a situation!</small> | | | | | |
| <input type="button" value="Apply"/> <input type="button" value="delete"/> | | | | | |



NOTE:


Mode select to **Bridge**. Check **Enable Vlan** and Vlan ID input **200**. Service Mode select to **Other**. Bind port check **Port_2**.

2. Configure IGMP

Click **Application**→ **IGMP Config**→ **IGMP Snooping**. Enable IGMP Snooping.




Click **Application** → **Multicast Vlan** → **3_Other_B_VID_200** → **Modify**. Input 200 in vlan multicast (blank said set).



3. Check ONU Status

Click **Status** → **Internet Info**



----End

3.3.5 Configuring Gateway ONU Internet Service – Broadcom chip scheme

ONU

Prerequisites

- The OLT is connected to the uplink device success
- The OLT create internet vlan
- The OLT configure GE port vlan for Internet
- The OLT configure PON port vlan for Internet
- The ONU is registered

1. Configuring IPoE WAN in ONU Web

Click **Advanced Setup** → **WAN** → **Add**

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

Wide Area Network (WAN) Service Setup

Choose Add, Remove or Edit to configure a WAN service over a selected interface.

| Interface | Description | Type | VLAN priority | VLAN ID | TPID | MTU | Multicast VLAN | IGMP Proxy |
|-----------|--------------|------|---------------|---------|--------|------|----------------|------------|
| epon0.1 | 1_TR069_R_50 | IPoE | 0 | 50 | 0x8100 | 1450 | -1 | Disable |

Click Next

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

WAN Service Interface Configuration

Select a layer 2 interface for this service

Click Next

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

WAN Service Configuration

Select WAN service type

- PPP over Ethernet (PPPoE)
- IP over Ethernet (IPoE)
- Bridging

Enter Service Description

For tagged service, enter valid 802.1P Priority and 802.1Q VLAN ID
For untagged service, set -1 to both 802.1P Priority and 802.1Q VLAN ID

Enter 802.1P Priority [0-7]:
 Enter 802.1Q VLAN ID [0-4094]:
 Multicast VLAN [-1 or 0-4094]:
 Select VLAN TPID:

Network Protocol Selection

NOTE:

WAN service type select to **IP over Ethernet(IPoE)**. Service Description select to **INTERNET**. 802.1Q VLAN ID[0-4094] input **100**.

Internet service document take DHCP mode as an example. The service type please selected

according to the user's actual use. ONT detail usage please refer to ONT user manual.

Click Next

Device Info
Advanced Setup
WAN
LAN
NAT
Firewall
Parental Control
Quality of Service
Routing
DNS
UPnP
DNS Proxy
Interface Grouping
Multicast
Wireless
Voice
Diagnostics
Management
Logout

WAN IP Settings

Enter information provided to you by your ISP to configure the WAN IP settings.
Notice: If "Obtain an IP address automatically" is chosen, DHCP will be enabled for PVC in IPoE mode.
If "Use the following Static IP address" is chosen, enter the WAN IP address, subnet mask and interface gateway.

Obtain an IP address automatically

Option 60 Vendor ID (8 hexadecimal digits)

Option 61 IAID (hexadecimal digits)

Option 125 Disable Enable

Use the following Static IP address

WAN IP Address

WAN Subnet Mask

WAN gateway IP Address



NOTE:

WAN IP Settings click **Obtain an IP address automatically** if topology use DHCP. If topology use static IP. Click **Use the following Static IP address** and input the IP address, Subnet Mask and gateway IP address.

Click Next

Device Info
Advanced Setup
WAN
LAN
NAT
Firewall
Parental Control
Quality of Service
Routing
DNS
UPnP
DNS Proxy
Interface Grouping
Multicast
Wireless
Voice
Diagnostics
Management
Logout

Network Address Translation Settings

Network Address Translation (NAT) allows you to share one Wide Area Network (WAN) IP address for multiple computers on your Local Area Network (LAN)

Enable NAT

Enable Fullcone NAT

Enable Firewall

IGMP Multicast

Enable IGMP Multicast Proxy

Enable IGMP Multicast Source

The maximum allowed size of an Ethernet frame

MTU [576-1500]:

Click Next

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

Routing -- Default Gateway

Default gateway interface list can have multiple WAN interfaces served as system default gateways but only one will be used according to priority order. Priority order can be changed by removing all and adding them back in again.

Selected Default Gateway Interfaces

epon0.2

->

<-

Available Routed WAN Interfaces

epon0.1

Back
Next

Click Next

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

DNS Server Configuration

Select DNS Server Interface from available WAN interfaces OR enter static DNS server IP addresses for the system. In ATM mode, if only **DNS Server Interfaces** can have multiple WAN interfaces served as system dns servers but only one will be used according to the priority order can be changed by removing all and adding them back in again

Select DNS Server Interface from available WAN interfaces:

Selected DNS Server Interfaces

epon0.1

->

<-

Available WAN Interfaces

epon0.2

Use the following Static DNS IP address:

Primary DNS Server

Secondary DNS Server

Back
Next

Click Apply/Save

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP

| Connection Type | IPoE |
|-------------------------------|---------|
| NAT | Enable |
| Enable Fullcone NAT | Disable |
| Firewall | Disable |
| IGMP Multicast Proxy | Disable |
| IGMP Multicast Source | Disable |
| MLD Multicast Proxy: | Disable |
| MLD Multicast Source Enabled: | Disable |
| Quality Of Service | Disable |

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications

Back
Apply/Save

2. Check ONU Status

Click **Device Info** → **WAN**

| |
|----------------|
| Device Info |
| Summary |
| WAN |
| Statistics |
| Route |
| ARP |
| DHCP |
| Voice |
| Optic |
| Advanced Setup |

WAN Info

| Interface | Description | Type | VLAN ID | MTU | IPv6 | IGMP Proxy | IGMP SRC Enable | MLD Proxy | MLD SRC Enable | NAT | Firewall | Status | IPv4 Address | IPv6 Address |
|-----------|------------------|------|---------|------|---------|------------|-----------------|-----------|----------------|--------|----------|------------|--------------|--------------|
| epon0.1 | 1_TR069_R_50 | IPoE | 50 | 1450 | Disable | Disable | Disable | Disable | Disable | Enable | Enable | Connecting | 0.0.0.0 | |
| epon0.2 | 2_INTERNET_R_100 | IPoE | 100 | 1492 | Disable | Disable | Disable | Disable | Disable | Enable | Disable | Connected | 192.168.5.14 | |

3. 3.6 Configuring Gateway ONU IPTV Service – Broadcom chip scheme ONU

Prerequisites

- The OLT is connected to the uplink device success
- The OLT create IPTV vlan
- The OLT configure GE port vlan for IPTV
- The OLT configure PON port vlan for IPTV
- The OLT configure IGMP and Multicast vlan
- The ONU is registered

1. Configuring Bridge WAN in ONU Web

Click **Advanced Setup**→**WAN**→**Add**

| |
|-----------------------|
| Device Info |
| Advanced Setup |
| WAN |
| LAN |
| NAT |
| Firewall |
| Parental Control |
| Quality of Service |
| Routing |
| DNS |
| UPnP |
| DNS Proxy |
| Interface Grouping |
| Multicast |
| Wireless |
| Voice |
| Diagnostics |
| Management |
| Logout |

Wide Area Network (WAN) Service Setup

Choose Add, Remove or Edit to configure a WAN service over a selected interface.

| Interface | Description | Type | VLAN priority | VLAN ID | TPID | MTU | Multicast VLAN | IGMP Proxy |
|-----------|------------------|------|---------------|---------|--------|------|----------------|------------|
| epon0.1 | 1_TR069_R_50 | IPoE | 0 | 50 | 0x8100 | 1450 | -1 | Disable |
| epon0.2 | 2_INTERNET_R_100 | IPoE | 0 | 100 | 0x8100 | 1492 | -1 | Disable |

Click **Next**

| |
|-----------------------|
| Device Info |
| Advanced Setup |
| WAN |
| LAN |
| NAT |
| Firewall |
| Parental Control |
| Quality of Service |
| Routing |
| DNS |
| UPnP |
| DNS Proxy |
| Interface Grouping |
| Multicast |
| Wireless |
| Voice |
| Diagnostics |
| Management |
| Logout |

WAN Service Interface Configuration

Select a layer 2 interface for this service

Click **Next**

Device Info

Advanced Setup

WAN

LAN

NAT

Firewall

Parental Control

Quality of Service

Routing

DNS

UPnP

DNS Proxy

Interface Grouping

Multicast

Wireless

Voice

Diagnostics

Management

Logout

WAN Service Configuration

Select WAN service type

PPP over Ethernet (PPPoE)

IP over Ethernet (IPoE)

Bridging

Allow as IGMP Multicast Source

Allow as MLD Multicast Source

Enter Service Description:

For tagged service, enter valid 802.1P Priority and 802.1Q VLAN ID
For untagged service, set -1 to both 802.1P Priority and 802.1Q VLAN ID

Enter 802.1P Priority [0-7]:

Enter 802.1Q VLAN ID [0-4094]:

Multicast VLAN [-1 or 0-4094]:

Select VLAN TPID:

NOTE:

WAN service type select to **Bridging**. Check **Allow as IGMP Multicast Source**. Service Description select to **Other**. 802.1Q VLAN ID[0-4094] input **200**. Multicast VLAN[-1 or 0-4094] input **200**.

Click Apply/Save

Device Info

Advanced Setup

WAN

LAN

NAT

Firewall

Parental Control

Quality of Service

Routing

DNS

UPnP

DNS Proxy

Interface Grouping

Multicast

Wireless

Voice

Diagnostics

Management

Logout

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP

| | |
|-------------------------------|-----------|
| Connection Type | undefined |
| NAT | Enable |
| Enable Fullcone NAT | Disable |
| Firewall | Disable |
| IGMP Multicast Proxy | Disable |
| IGMP Multicast Source | Enable |
| MLD Multicast Proxy: | Disable |
| MLD Multicast Source Enabled: | Disable |
| Quality Of Service | Disable |

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications

Click Advanced Setup → Interface Grouping

Device Info

Advanced Setup

WAN

LAN

NAT

Firewall

Parental Control

Quality of Service

Routing

DNS

UPnP

DNS Proxy

Interface Grouping

Multicast

Wireless

Voice

Diagnostics

Management

Logout

Interface grouping Configuration

To create a new interface group:

- Enter the Group name and the group name must be unique and select either 2. (dynamic) or 3. (static) below:
- If you like to automatically add LAN clients to a WAN Interface in the new group add the DHCP vendor ID string. By configuring a DHCP vendor ID string any DHCP client request with the specific IP address from the local DHCP server.
- Select interfaces from the available interface list and add it to the grouped interface list using the arrow buttons to create the required mapping of the ports. **Note that these clients may omit**
- Click Apply/Save button to make the changes effective immediately

IMPORTANT If a vendor ID is configured for a specific client device, please REBOOT the client device attached to the modem to allow it to obtain an appropriate IP address.

Group Name:

WAN Interface:

Grouped LAN Interfaces

eth1.0

Available LAN Interfaces

eth0.0

eth2.0

eth3.0

wlan0

wi0_Guest80FEGU|wi0.1


wi0_Guest80FEGU|wi0.2

wi0_Guest80FEGU|wi0.3

 **NOTE:**

Group Name free to enter. WAN Interface select to **3_Other_B_200/epon0.3**. Move **eth1.0** to Grouped LAN interface. The purpose of this step is isolate LAN2 with other LAN port avoid multicast packet flood to other LAN port. If eth1.0(LAN2) move to Grouped LAN interface. LAN2 only can receive multicast traffic. Internet is not work on LAN2. This step is not necessary but recommended.

Click **Advanced Setup** → **Interface Grouping** to check Interface group status



Device Info
Advanced Setup
WAN
LAN
NAT
Firewall
Parental Control
Quality of Service
Routing
DNS
UPnP
DNS Proxy
Interface Grouping
Multicast
Wireless
Voice
Diagnostics
Management
Logout

Interface Grouping

Interface Grouping supports multiple ports to PVC and bridging groups. Each group will perform as an independent network. To support this feature, you must create mapping groups button will remove the grouping and add the ungrouped interfaces to the Default group. Only the default group has IP interface

| Group Name | Remove | WAN Interface | LAN Interface | DHCP Vendor IDs |
|------------|--------------------------|---------------|---------------|-----------------------|
| Default | <input type="checkbox"/> | | epon0.1 | eth0.0 |
| | | | epon0.2 | eth2.0 |
| | | | | eth3.0 |
| | | | | wlan0 |
| | | | | w10_Guest80FEGU/wi0.1 |
| | | | | w10_Guest80FEGU/wi0.2 |
| IPTV | <input type="checkbox"/> | epon0.3 | eth1.0 | |

3. 3.7 Configuring Gateway ONU VOIP Service – Broadcom chip scheme ONU

Prerequisites

- The OLT is connected to the uplink device success
- The OLT create VOIP vlan
- The OLT configure GE port vlan for VOIP
- The OLT configure PON port vlan for VOIP
- The ONU is registered

1. Configuring IPoE WAN in ONU Web

Click **Advanced Setup** → **WAN** → **Add**

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

Wide Area Network (WAN) Service Setup

Choose Add, Remove or Edit to configure a WAN service over a selected interface.

| Interface | Description | Type | VLAN priority | VLAN ID | TPID | MTU | Multicast VLAN | IGMP Proxy |
|-----------|------------------|--------|---------------|---------|--------|------|----------------|------------|
| epon0.1 | 1_TR069_R_50 | IPoE | 0 | 50 | 0x8100 | 1450 | -1 | Disable |
| epon0.2 | 2_INTERNET_R_100 | IPoE | 0 | 100 | 0x8100 | 1492 | -1 | Disable |
| epon0.3 | 3_Other_B_200 | Bridge | 0 | 200 | 0x8100 | 1492 | -1 | Disable |

Click Next

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

WAN Service Interface Configuration

Select a layer 2 interface for this service

Click Next

- Device Info
- Advanced Setup
- WAN
- LAN
- NAT
- Firewall
- Parental Control
- Quality of Service
- Routing
- DNS
- UPnP
- DNS Proxy
- Interface Grouping
- Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

WAN Service Configuration

Select WAN service type

- PPP over Ethernet (PPPoE)
- IP over Ethernet (IPoE)
- Bridging

Enter Service Description

For tagged service, enter valid 802.1P Priority and 802.1Q VLAN ID
For untagged service, set -1 to both 802.1P Priority and 802.1Q VLAN ID

Enter 802.1P Priority [0-7]:
 Enter 802.1Q VLAN ID [0-4094]:
 Multicast VLAN [-1 or 0-4094]:
 Select VLAN TPID

Network Protocol Selection

NOTE:

WAN service type select to **IP over Ethernet(IPoE)**. Service Description select to **VOICE**. 802.1Q VLAN ID[0-4094] input **300**.

Click Next

- Device Info
- Advanced Setup
 - WAN
 - LAN
 - NAT
 - Firewall
 - Parental Control
 - Quality of Service
 - Routing
 - DNS
 - UPnP
 - DNS Proxy
- Interface Grouping
 - Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

WAN IP Settings

Enter information provided to you by your ISP to configure the WAN IP settings.
Notice: If "Obtain an IP address automatically" is chosen, DHCP will be enabled for PVC in PoE mode.
If "Use the following Static IP address" is chosen, enter the WAN IP address, subnet mask and interface gateway.

Obtain an IP address automatically

Option 60 Vendor ID

Option 61 IAID (8 hexadecimal digits)

Option 61 DUID (hexadecimal digits)

Option 125 Disable Enable

Use the following Static IP address

WAN IP Address

WAN Subnet Mask

WAN gateway IP Address

Back Next



NOTE:

WAN IP Settings click **Use the following Static IP address** and input the IP address, Subnet Mask and gateway IP address if topology use static ip. If topology use DHCP. Click **Obtain an IP address automatically**.

Click Next

- Device Info
- Advanced Setup
 - WAN
 - LAN
 - NAT
 - Firewall
 - Parental Control
 - Quality of Service
 - Routing
 - DNS
 - UPnP
 - DNS Proxy
- Interface Grouping
 - Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

Network Address Translation Settings

Network Address Translation (NAT) allows you to share one Wide Area Network (WAN) IP address for multiple computers on your Local Area Network (LAN)

- Enable NAT
- Enable Fullcone NAT
- Enable Firewall

IGMP Multicast

- Enable IGMP Multicast Proxy
- Enable IGMP Multicast Source

The maximum allowed size of an Ethernet frame

MTU [576-1500]:

Back Next

Click Next

- Device Info
- Advanced Setup
 - WAN
 - LAN
 - NAT
 - Firewall
 - Parental Control
 - Quality of Service
 - Routing
 - DNS
 - UPnP
 - DNS Proxy
- Interface Grouping
 - Multicast
- Wireless
- Voice
- Diagnostics
- Management
- Logout

Routing -- Default Gateway

Default gateway interface list can have multiple WAN interfaces served as system default gateways but only one will be used according to the priority can be changed by removing all and adding them back in again.

Selected Default Gateway Interfaces

epon0.2



Available Routed WAN Interfaces

epon0.4
epon0.1

Back Next

Click Next

Device Info

Advanced Setup

WAN

LAN

NAT

Firewall

Parental Control

Quality of Service

Routing

DNS

UPnP

DNS Proxy

Interface Grouping

Multicast

Wireless

Voice

Diagnostics

Management

Logout

DNS Server Configuration

Select DNS Server Interface from available WAN interfaces OR enter static DNS server IP addresses for the system. In ATM mode, if only a single PVC **DNS Server Interfaces** can have multiple WAN interfaces served as system dns servers but only one will be used according to the priority with the changed by removing all and adding them back in again

Select DNS Server Interface from available WAN interfaces:

Selected DNS Server Interfaces

epon0.2

>

<

Available WAN Interfaces

epon0.4
epon0.1

Use the following Static DNS IP address:

Primary DNS Server

Secondary DNS Server

[Back](#) [Next](#)

Click Apply/Save

Device Info

Advanced Setup

WAN

LAN

NAT

Firewall

Parental Control

Quality of Service

Routing

DNS

UPnP

DNS Proxy

Interface Grouping

Multicast

Wireless

Voice

Diagnostics

Management

Logout

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP

| Connection Type | IPoE |
|------------------------------|---------|
| NAT | Enable |
| Enable Fullcone NAT | Disable |
| Firewall | Disable |
| IGMP Multicast Proxy | Disable |
| IGMP Multicast Source | Disable |
| MLD Multicast Proxy | Disable |
| MLD Multicast Source Enabled | Disable |
| Quality Of Service | Disable |

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications

[Back](#) [Apply/Save](#)

Click **Device Info** → **WAN**, 查看 ONU 所配置的 WAN 的信息。

Device Info

Summary

WAN

Statistics

Route

ARP

DHCP

Voice

Optic

Advanced Setup

Wireless

Voice

Diagnostics

Management

Logout

WAN Info

| Interface | Description | Type | VLAN ID | MTU | IPv6 | IGMP Proxy | IGMP SRC Enable | MLD Proxy | MLD SRC Enable | NAT | Firewall | Status | IPv4 Address | IPv6 Address |
|-----------|------------------|--------|---------|------|---------|------------|-----------------|-----------|----------------|---------|----------|------------|--------------|--------------|
| epon0.1 | 1_TRO69_R_50 | IPoE | 50 | 1450 | Disable | Disable | Disable | Disable | Disable | Enable | Enable | Connecting | 0.0.0.0 | |
| epon0.2 | 2_INTERNET_R_100 | IPoE | 100 | 1492 | Disable | Disable | Enable | Disable | Disable | Enable | Disable | Connected | 192.168.5.14 | |
| epon0.3 | 3_Other_B_200 | Bridge | 200 | 1492 | Disable | Disable | Enable | Disable | Disable | Disable | Disable | Connected | 0.0.0.0 | |
| epon0.4 | 4_VOICE_R_300 | IPoE | 300 | 1492 | Disable | Disable | Disable | Disable | Disable | Enable | Disable | Connected | 192.168.0.17 | |

2. Configuring Voice in ONU Web

Click **Voice** → **SIP Basic Setting**

Global parameters | **Service Provider 0**

Voice -- SIP configuration

Enter the SIP parameters and click Start/Stop to save the parameters and start/stop the voice application

Locale selection* CHN - CHINA (Note: Requires the SIP client to be stopped and then started to take affect)

SIP Domain name*:

Dialplan

Use SIP Proxy
 SIP Proxy:
 SIP Proxy Port:

Use SIP Outbound Proxy
 SIP Outbound Proxy:
 SIP Outbound Proxy Port:

Use SIP Registrar
 SIP Registrar:
 SIP Registrar Port:

| SIP Account | 0 | 1 |
|------------------------------|--|--|
| Enabled | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> |
| Extension | 88880001 | 88880002 |
| Display name | 88880001 | 88880002 |
| Authentication name | 88880001 | 88880002 |
| password | 88880001 | 88880002 |
| Physical Terminal Assignment | <input checked="" type="checkbox"/> FXS 0 <input checked="" type="checkbox"/> FXS 1 | <input checked="" type="checkbox"/> FXS 0 <input checked="" type="checkbox"/> FXS 1 |
| Preferred ptime | <input type="text" value="20"/> | <input type="text" value="20"/> |

NOTE:

SIP Proxy, SIP Outbound Proxy, SIP Registrar enter SIP server IP address. Extension, Display name, Authentication name, password enter base on user actual setting.

Click **Device Info** → **Voice**

- Device Info
- Summary
- WAN
- Statistics
- Route
- ARP
- DHCP
- Voice
- Optic
- Advanced Setup
- Wireless
- Voice
- Diagnostics
- Management
- Logout

Voice Info -- H.248/SIP

| Name | Registration Status | Call Status |
|----------|---------------------|-------------|
| 88880001 | Up | Idle |
| 88880002 | Up | Idle |

NOTE:

If Registration Status is **Up** mean voice account register successfully.

----End